

INTELLIGENT SYSTEMS ENGINEERING DEPARTMENT THE NATIONAL SCHOOL OF ARTIFICIAL INTELLIGENCE

3RD YEAR, SEMESTER 1 - 2023/2024

NETWORKS AND PROTOCOLS

Lab 2

Introduction

The aim of this tutorial is to learn how to connect the different parts of a local network, configure terminal machines by assigning them an identity in terms of IP (Internet Protocol) address, and test connectivity between these machines. The following tasks will be carried out:

- Correctly identify the cables to be used within the network,
- Use "Packet Tracer" software to create and configure each individual architectures,
- Physically connect a machine-to-machine network and a switched network,
- Check the basic connectivity of each PC,

Task 1: Creating a machine-to-machine network




Figure 1: Machine to machine

Step 1: Connect the two workstations PC1 and PC2

- Connect the two workstations using the appropriate Ethernet cable,
- Connect one end of the cable to the network interface on PC1 and the other to PC2,
- Which cable is used?

Step 2: Define a Layer 3 address for each workstation.

- Click on each terminal and go to the "Config" tab, the window below appears,
- Enter IP addresses for each station as shown above,
 - PC1 has the IP address: 192.168.1.2
 - PC2 has the IP address: 192.168.1.3
- Ensure that the "On" button is activated.

Note: The same configuration can also be performed from the "Desktop" tab, as shown in the figure 3:




Figure 2: PC config page




Figure 3: PC Desktop config page

Step 3: Checking the connectivity of PC1 and PC2 stations

- Click on each station, and the previous window appears,
- Go to the "Desktop" tab, the window below appears (Figure 4).
- Click on "Command Prompt", the command line appears.
- Type the ping command as shown in the "Command Prompt" window (Figure 5),
- On PC1, enter the address of PC2 and on PC2, enter the address of PC1,



Figure 4: PC Desktop App page

```
Command Prompt

Packet Tracer PC Command Line 1.0
PC>ping 192.168.1.3

Pinging 192.168.1.3 with 32 bytes of data:
```

Figure 5: PC Command Prompt

• If the ping responds with a reply, connectivity is successful (Figure 6).




Figure 6: Ping positive response

• If the ping responds with a Timeout or Host Destination Unreachable (see figure 7),

connectivity has failed. In the latter case, you need to troubleshoot the network by checking the configuration of each machine.

Figure 7: Ping negative response

Task 2: Creating a switched network with Packet Tracer




Figure 8: Switched network

Step 1: Connect a workstation to the switch.

- Connect one end of the appropriate Ethernet cable to the network interface of a workstation,
- Connect the other end to one of the switch ports,
- Do the same with the other workstation. Select any port on the switch,
- Which cable should we use?
- Step 2: Define a Layer 3 address for each workstation.
- Step 3: Check connectivity using the ping command.

Task 3: Creation of a network using hardware from the network room (using the same network ID)

- Step 1: Please connect to the ENSIA network (via WiFi or Ethernet cable).
- **Step 2:** Define a Layer 3 address for each PC.
 - We will use the same network address for all machines (we can use the provided IP address from our HDCP server)
 - Obtain your IP address (using ifconfig or ipconfig)
 - What is your IP address?

Note: IP address configuration window may vary from one machine to another, depending on the operating system or version. However, the principle is the same.

Step 3: Check the connectivity of both PCs

- From the source host, launch the terminal or command prompt
- Type the ping command as explained above,
- Indicate the average RTT value

Task 4: Creation of a network using hardware from the network room (using different network ID)

- Step 1: Please connect to the ENSIA network (via WiFi or Ethernet cable).
- **Step 2:** Define a Layer 3 address for each PC.
- We will split the room into two different (logical) network addresses
 - One half using the network address 192.168.0.0 /24
 - Other half using the network address: 192.168.1.0 /24

Note: IP address configuration window may vary from one machine to another, depending on the operating system or version. However, the principle is the same.

Step 3: Check the connectivity of both PCs

- From the source host, launch the terminal or command prompt
- Type the ping command as explained above,
- Why the ping doesn't work?